


KitchenAid®

OVEN PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
(Black) (White) (Biscuit) (Stainless Steel)

30" BUILT-IN ELECTRIC
DOUBLE OVEN
THERMAL CONVECTION LOWER
MICROWAVE CONVECTION UPPER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			6	4452490	Spacer, Foam	37	4451442	Thermostat (TOD) (Temp.) SPST
			7	4455286	Top Chassis		4449809	Screw
				4449809	Screw	43	4455530	Base, Chassis
			9	4452158	Tube, Vent		4449809	Screw
				3196176	Screw	49	4448933	Retainer, Gasket
1		Literature Parts	10	4452163	Lens, Light		4449154	Screw
	LIT8300653	Installation Instructions	11	4448972	Oven Light Assy	50	4451747	Cover, Back
	LIT8300953	Use & Care Guide (Oven)	12	4452164	Bulb, Light		4449809	Screw
	LIT8300890	Use & Care Guide (Microwave)	14	4455612	Frame, Front	51		Trim, Bottom
	LIT4450786	Cooking Guide (Lable)		4449040	Screw		4455443	Black
	LIT4452295	Tech Sheet (Oven)	15	4455382	Gasket, Door		4455445	White
	LIT4449264	Easy Set Guide	19	4451478	Support, Insulation		4455447	Biscuit
	LIT3191638	Safer Cooking Tips	20	4451605	Cap, Spacer		4455147	Stainless Steel
	LIT4451052	Easy Use Guide (Microwave)	21		Rail, Side		3400805	Screw
		Hinge Reciever		4450583	Right Side		4452152	Bracket, Vent Mounting
3		Left Hand		4450584	Left Side	52	4451756	Chassis, Back
	4455605	Right Hand		4448444	Grommet	53	4452492	Insulation, Convection Top
	4455606	Bumper, Door	25	4455641	Screw		4452491	Insulation, Convection Grill
4		Trim, Side			Side, Chassis (R.H. & L.H.)			
5		RH Black		4449809	Screw			
	4455430	RH Biscuit	26	4452234	Back, Chassis			
	4455434	RH White		4449809	Screw			
	4455432	Stainless Steel	27		Liner, Oven (Not serviceable)			
	4452083	LH Black	29	4455636	Sensor			
	4455431	LH Biscuit		4449154	Screw			
	4455435	LH Biscuit	30	4449845	Bracket, Support			
	4455433	LH White		4449809	Screw			
	4452084	Stainless Steel Screw	33	4452496	Deflector, Vent			
	8281236	Black	34	4451667	Vent, Center			
	694091	Zink		4450038	Screw			


**FOLLOWING PARTS
NOT ILLUSTRATED**

INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back
4452337	Insulation, Bottom Vent

CONTROL PANEL PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Panel. Control
	4452604	Black
	4452605	White
	4452974	Biscuit
	4451791	Stainless Steel
2		Switch Membrane
	4455481	Black
	4455485	White
	4455483	Biscuit
	4452329	Stainless Steel
3	4452248	Insulator, Board
4	4452249	Insulator, Board Support
	3400832	Screw
5	4452260	Spacer, Foam
6	4452345	Insulator, Dielectric
7	4453377	Microcomputer
	3400406	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: KEMC308KBLO, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			5	8300778	Retainer, Glass	14	4452959	Bracket, Handle Right Hand
1	4455618	Door Liner	4449809		Screw		4452960	Bracket, Handle Left Hand
2	8300575	Hinge, Door Rt Side (clear)	7	4449263	Glass, Inner	19	3196184	Screw
	8300576	Lft Side (clear)	12	4455391	Door Glass, Assy Black		4450362	Shield, Heat
	8300577	Rt Side (yellow)		4455390	White		4449809	Screw
	8300578	Lft Side (yellow)		445395	Biscuit	20	4451668	Retainer, Glass
	4449743	Screw		4452316	Stainless Steel		4449809	Screw
3	4449259	Glass, Inner	13	4452502	Door Handle Black	23	4450863	Retainer, Glass-Clip Black
4	4451722	Insulation, Door		4452503	White		4450864	Retainer, Glass-Clip White
				4452871	Biscuit		4452119	Retainer, Glass-Clip Almond
				4452088	Stainless Steel		4451432	Retainer, Glass-Clip Stainless Steel
						24	4455257	Glass, Inner
						25	4452326	Seal, Pano

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LATCH PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
(Black) (White) (Biscuit) (Stainless Steel)



**Illus. Part
No. No. DESCRIPTION**

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
2	4455178	Elbow, Vent-Top
5	4455177	Elbow, Vent-Bottom
6	4451758	Seal, Foam
9	4450408	Baffle, Rear
	4449154	Screw
10	4451424	Latch Assy.
11	4451663	Solenoid
12	4452312	Micro Switch N.C.
13	4451426	Micro Switch
14	4451537	Spring, Latch
	4449154	Screw
16	6610168	Blower
	4449809	Screw
19	4449906	EXT Filler
	4455191	Plate, Service

IMPORTANT PRODUCT SAFETY INFORMATION

ADVISE CONSUMERS OF AN ELECTROCUTION HAZARD WITH DO-IT-YOURSELF REPAIRS OF MICROWAVE OVENS.


The U.S. Consumer Product Safety Commission warns against do-it-yourself repairs of microwave ovens. Microwave ovens use high voltage which makes it particularly hazardous for consumers to remove the cover and touch electrical parts.

STRONGLY RECOMMEND THAT CONSUMERS HAVE PROFESSIONALS REPAIR MICROWAVE OVENS.

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
2	4452156	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
5	3181534	Rack, Roasting
6	4448717	Rack, Oven
7	4452155	Element, Bake
8	4448881	Nut, Hex
9	4451583	Convection, Motor
	4449154	Screw
10	4452226	Blade, Fan
11	4448882	Washer, Lock
12	4452227	Nut
13	4451355	Jack, Meat Probe
14	4448948	Probe, Meat
15	4455037	Tray, Bake
17	4450039	Cover, Bake Tray
	4449809	Screw
20	4452157	Element, Convection
	4449154	Screw
21	4448418	Cover, Fan
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET AND STIRRER PARTS


For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	4375437	Bracket, Capacitor	32	4375281	Thermostat	55	4375422	Sensor, Temp.
3	4375252	Rubber Ring	33	4375408	Q Tube Assembly	56	4375420	Insulation
4	4375038	Screw	34	4375438	Transformer	57	4375419	Duct, Heater
5	4375314	Air Duct, Magnetron	35	4375406	Ring, Turntable	58	4375416	Washer
6	4375253	Support, Tube	36	4375407	Shaft, Turntable	59	4375417	Element, Heater
7	4375421	Plug, Ceramic	39		Bracket, Hinge	60	4375418	Fan
8	4375255	Bushing		4375412	Left	61	4375429	Motor, Fan
9	4375256	Reflector		4375413	Right	62		Left-Threaded Nut Serviced With Motor Item 61
10	4375257	Chamber, Reflector	42	4375331	Plate, Grill			
12	4375450	Duct, Inlet	43	4375332	Bracket			
13	4375316	Insulation, Switch	44	4375441	Fan Cap	63	4375430	Thermostat
14	4375322	Fan Wheel	46		Switch Holder	64	4375431	Shield, Heat
15	4375317	Duct, Air		4375412	Left	65	4375432	Insulation
16	4375415	Block, Slide		4375413	Right	66	4375433	Chamber, Heat
17	4375248	Cover Plate, Upper	47	4375258	Nut			Cabinet
18	4375251	Screw	48		Insulation	67	4375437	Isolation Plate
19	4375318	Lens, Lamp		4375409	Left Side	68	4375338	Cover Plate
20	4375319	Spring		4375410	Right Side	71		Side Plate
21	4375320	Reflector	49	4375411	Plate, Side		4375341	Left
23	4375276	Rack			Bottom		4375342	Right
24	4393536	Crisp Plate	50	4375425	Valve	72	4375405	Turntable
25	4375436	Capacitor	51	4375428	Screw To Valve	73	4375346	Switch
26	4375424	Magnetron	52	4375427	Thermoactuator	74	4375347	Motor, Turntable
27	4375321	Fuse	53	4375426	Air Bleed	75	4375348	Lamp
28	4375231	Block, Fuse	54	4375439	Shield, Heat	76	4375349	Rectifier
29	4375278	Motor, Blower			Right	77	4452220	Rack, Convection
30	4375279	Thermostat						
31	4375423	Thermostat						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE COMPARTMENT PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)




Illus. No.	Part No.	DESCRIPTION
5		Support Rails
	4452551	Right Side
	4452552	Left Side
	4449809	Screw
11	4452548	Rear Channel
	4449809	Screw
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)



Illus. Part No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

- 1 4450378 Cover, Top
4449809 Screw
- 2 4448935 Baffle, Blower
1180485 Screw
- 3 4450920 Blower
4449809 Screw
- 4 4451789 Plate, Mounting
- 5 6610122 Transformer, (Lights)
4449809 Screw
- 6 4451634 Exhaust Duct
- 7 4450027 Bracket, Duct

Illus. Part No. DESCRIPTION

- 8 4449964 Grommet
4449809 Screw
112432 Nut
- 9 4454949 Holder, Fuse
4449154 Screw
- 10 4454976 Fuse
- 11 4449868 Block, Terminal
3400080 Screw
- 12 4452559 Side, Combo
4449809 Screw
- 13 4450791 Vent, (Control Panel)
4450038 Screw
- 14 4451597 Right
4451598 Left
4449809 Screw


Illus. Part No. DESCRIPTION

- 15 4452244 Back, Control
4449809 Screw
- 16 4450551 Cover, Top Rear
4449809 Screw
- 17 4448664 Clamp
4449809 Screw
- 18 4452367 Cover, Top Front
4449809 Screw
- 19 4455038 Transformer, Control
- 20 4452247 Cover, Plate
4449809 Screw
- 21 4451934 Suppressor

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MICROWAVE DOOR PARTS

For Models: KEMC308KBL0, KEMC308KWH0, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)



Illus. Part No. DESCRIPTION

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

- 1 4448937 Glass, Middle
- 2 4450946 Frame, Door
- 3 4450038 Screw
- 4 4450265 Tape, Foam
- 4 4449141 Bracket, Mounting
- 4 4449142 Right Side
- 4 4449142 Left Side
- 4 4449809 Screw

Illus. Part No. DESCRIPTION

- 5 4449083 Filler, Side
- 5 4449086 Right Side
- 5 4449086 Left Side
- 5 4449809 Screw
- 6 4452502 Handle, Door
- 6 4452502 Black
- 6 4452503 White
- 6 4452871 Biscuit
- 6 4452088 Stainless Steel
- 7 4452211 Glass, Outer
- 7 4452211 Black
- 7 4452789 White
- 7 4452995 Biscuit
- 7 4452259 Stainless (Assy)
- 9 4452331 Bracket, Handle
- 9 4451040 Screw

Illus. Part No. DESCRIPTION

- 10 4450863 Retainer, Glass-Clip
- 10 4450863 Black
- 10 4450864 White
- 10 4451432 Stainless Steel
- 11 4375339 Door, Plate
- 12 4375414 Frame, Inner
- 13 4375330 Strap, Door
- 14 4375313 Screw
- 15 4375323 Hinge, Door
- 15 4375323 Left
- 15 4375324 Right
- 16 4451009 Spring, Torsion
- 16 4451009 Right Hand
- 16 4452395 Left Hand

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: KEMC308KBLO, KEMC308KWHO, KEMC308KBT0, KEMC308KSS0
 (Black) (White) (Biscuit) (Stainless Steel)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

72017 White
 261869 Cord Brown
 72032 Black

PAINT, SPRAY

350930 White
 261900 Citrine White
 830864 Black

ADHESIVE

591014 Adhesive
 Loctite (1/3 oz.)
 482338 Sealer, Silastic
 (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES--25FT.

LENGTH

242828	Wire (12 Ga. 150 c Black)
242820	Wire (14 Ga. 150 c Black)
242821	Wire (14 Ga. 150 c Blue)
242822	Wire (14 Ga. 150 c Brown)
242830	Wire (14 Ga. 200 c Brown)
242823	Wire (14 Ga. 150 c Green)
242824	Wire (14 Ga. 150 c Orange)
242829	Wire (12 Ga. 150 c Red)
242825	Wire (14 Ga. 150 c Red)
242831	Wire (14 Ga. 200 c Red)
242826	Wire (14 Ga. 150 c White)
242827	Wire (14 Ga. 150 c Yellow)
242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

**FOLLOWING PARTS
NOT ILLUSTRATED**

4378944 Filler Kit (BL)
 4378945 Filler Kit (WH)
 4378946 Filler Kit (AL)

WIRING HARNESS PARTS

4452239 Harness, Latch
 4452400 Lead, Ground
 4449809 Screw
 4455732 Harness, Main
 4450831 Ground (M/W)
 4450800 Screw, Ground
 4449809 Screw
 4450950 Conduit, Combo
 313438 Clip, Harness
 4452222 Spacer, Harness
 4454835 Tie, Cable

Miscellaneous

4448950 Screw, Install (4)
 814381 Hinge Pin Kit